



GEN4 LEDs

<u>COLOR</u>	<u>LABEL</u>	<u>USE</u>
Green	PWR	Power Indicator – Should be green all the time.
Green/Red	GPS	GPS Receiver Status Steady Green – GPS Locked Flashing Red – Searching for Satellites – Pull outside or inspect antenna
Blue (yellow)	LNK	Radio Activity Bluetooth: Flashes when data is transmitted
Green/Red	EXP	Future use OBD II Diagnostic Activity
Green/Red	ACT	Activity Green – In trip Red – Overspeed, or excessive idling